



Open package. Within you will the blind cassette, side rails, recess mount frame and associated fixings



Begin by laying out three elements of recess mount frame as seen above.



Insert corner brackets as shown in preparation to join the left and right element to the top element



Join top element to left element via the corner bracket as shown by sliding the bracket into top slot



Join top element to right element via the corner bracket as shown by sliding the bracket into top slot



Raise assembled frame to mounting location. The frame is made to your exact specification.



If rawl plug is required, mark position on wall through pre-drilled locations as shown.



If no rawl plug is required, fix screw through pre drilled locations. Following Insertion of rawl plug screw in



Raise cassette to frame and slide on over pre-assembled brackets on surface mount frame

Eco Thermal

Installation Guide Surface Mount-2



Fix cassette to block: Rotate handle and Insert screw provided into position



Fix screw into block. A cordless drill may be required to screw through into block. Repeat for right hand side



Fix siderail to cassette mount frame: Slide fabric into track of siderail as shown



Slide siderail under cassette as shown and rotate the siderails into position



Take provided screws to be fitted through pre drilled holes in siderails



Screw Into position.

