

How to fit venetian blinds

1 During the ordering process, you will have selected either 'inside recess' or 'outside recess' measurement's.

outside recess - face fix brackets

inside recess - top fix or face fix brackets

2 Brackets

There are 5 different brackets available for venetian blinds, 2 top fix and three universal brackets (top and face fix).

Follow the instructions for the brackets that you received with your blinds.

swivel bracket
 top fix top fix & face fix

push-fit bracket
 top fix top fix & face fix

cage bracket
 top fix & face fix

3 Swivel Bracket

These brackets can fit anywhere along the blind.

Slide the bracket in to the head rail and then swivel the bracket arm clockwise to lock the blind in position

Do not put brackets near cord lock or wand tilter.

When fitting hook the front of headrail into front of bracket
 Twist rail backwards so it locates into the back of the bracket.

Turn Lever Clockwise to lock in position.

4 Push-Fit Bracket

This bracket can fit anywhere along the blind. I would recommend fitting a bracket 5cm in from each end of the blind.

After the brackets have been installed, push the front edge of the blind against the front of the brackets (note - the brackets are spring loaded)

The brackets should compress and then allow the back of the blind to hook into the position shown

Follow the same procedure as above if the blind needs removing. Push the blind forwards against the spring and lower the back of the blind to release it

5 Cage Bracket

These brackets come in a pair, one for each end of the blind.

The brackets can be fitted using any of the holes.

6 Controls

There are two controls for a venetian blind. One to lift / lower the blind and another control to tilt the slats (sometimes a cord control instead of wand control)

Pull the cords:
LEFT to lower and raise the blind
RIGHT to lock the blind in position

Turn the wand in either direction to tilt the slats forward or backwards.

In the box

x4

x2

x2

or

x2

or

x1

Tools Suggested

screwdriver
 drill (5mm)
 pencil
 tape measure
 spirit level